

Mode key

Change the current lighting mode (ineffective in DMX mode) with 16 modes:

Mode1	red	Mode9	Warm white
Mode2	Green	Mode10	3 colors jump changing
Mode3	Blue	Mode11	9 colors jump changing
Mode4	Yellow	Mode12	7 colors gradual changing
Mode5	Purple	Mode13	Red and green gradual changing
Mode6	Cyan	Mode14	Red and blue gradual changing
Mode7	Cool white	Mode15	Blue and green gradual changing
Mode8	Pure white	Mode16	The white colors gradual changing

Table 1a